AGPS User’s Manual (PC)

VENUS 5 series AGPS

AGPS Infrastructure



Method A:

STEP 1: Connect your GPS device

Connect your GPS device to PC, Choose Com Port and Baudrate
Click Connect See the NMEA Message





PS: Make sure your internet was connected

STEP 2: AGPS data download

Choose AGPS Download





Automatic connect to internet and download to Flash memory

STEP 3: AGPS Download finish

Set Ephemeris Successful





Option : AGPS Enable or Disable

Option : AGPS Status(7 days 1 hours)

Method B:

STEP 1: Connect your GPS device

Connect your GPS device to PC, Click Auto to scan Com Port



PS: Make sure your internet was connected

Automatic connect to internet and download to Flash memory



Set Ephemeris Successful





Option : AGPS Enable or Disable

Option : AGPS Status(7 days 1 hours)

Method C:

STEP 1: Connect your GPS device

Connect your GPS device to PC
Choose Com Port and Baudrate
Click Connect
See the NMEA Message

PS: Make sure your internet was connected



STEP 2: AGPS data download

Click AGPS menu
Choose AGPS Download



STEP 3: Automatic download

Click Connect

Automatic connect to internet and download



STEP 4: AGPS data download to GPS flash memory

Automatic download data to Flash memory



STEP 5: AGPS Download finish

Click Warm Start you will see it fix very quickly



Option : AGPS Enable or Disable



Option : AGPS Status

6 days ,8 hours